

FIG. 1




FIG. 2




FIG. 3

FIG. 2




FIG. 4




FIG. 5

REMOTE VEHICLE POSITION  
REQUEST MESSAGE

OPR	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID
-----	--------------------------	-------------------------

OPR: REMOTE VEHICLE POSITION  
REQUEST CODE

FIG. 6




FIG. 7


TABLE 1505E60

VEHICLE POSITION SPONTANEOUS  
TRANSMISSION MESSAGE

CPT	ORIGINATING VEHICLE ID	DESTINATION VEHICLE ID	VEHICLE POSITION INFORMATION
-----	---------------------------	---------------------------	---------------------------------

CPT: VEHICLE POSITION  
SPONTANEOUS TRANSMISSION CODE

FIG. 8

[illegible]

# Fig. 9

FIG. 10

VEHICLE POSITION  
REQUEST MESSAGE

CPR	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER
-----	--------------------------	-------------------------	----------------

CPR::VEHICLE POSITION REQUEST CODE

FIG. 10

RETURN VEHICLE  
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	VEHICLE POSITION INFORMATION
-----	--------------------------	-------------------------	----------------------	---------------------------------

RCP:: RETURN VEHICLE POSITION CODE

FIG. 11




FIG. 12



RETURN VEHICLE  
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	ERR1
-----	--------------------------	-------------------------	-------------------	------

RCP: RETURN VEHICLE POSITION CODE

ERR1: FIRST ERROR CODE

FIG. 13

RETURN VEHICLE  
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	ERR2
-----	--------------------------	-------------------------	-------------------	------

RCP: RETURN VEHICLE POSITION CODE

ERR2: SECOND ERROR CODE

FIG. 14




FIG. 15

(REMOTE VEHICLE POSITION DISPLAY MODE)




FIG. 16




FIG. 17